



Foot Pedal Switch Layout


- 4-Pin connector
- 1) Red-52
 - 2) Purple-83
 - 3) Orange-56
 - 4) Blue-55



Secondary




COVER OFF
VIEW FROM TOP



DO NOT INVERT SWITCHES
When Removed -
double Term- 2 & 4 primary 5
go same side as Green screw

- Dimmer Switch
- Foot Switch
- Relays Yellow 156

COVER OFF
VIEW FROM TOP



not
Pedal
STEERING

